






- (F) Coffrets Gamma 18
- (GB) Enclosures Gamma 18
- (D) Verteiler Gamma 18
- (E) Cajas Gamma 18
- (P) Caixas Gamma 18
- (S) Normkapslingar Gamma 18
- (NL) Gamma 18 kast

- Notice d'instructions
- User instructions
- Bedienungsanleitung
- Instrucciones de uso
- Instruções
- Bruksanvisning
- Gebruiksaanwijzing

## GD 118, GD 218, GD 318, GD 418



	A (mm)	B (mm)	E (mm)	F (mm)	G (mm)	H (mm)
<b>GD 118.</b>	355	250	323	120	264	134
<b>GD 218.</b>	355	375	323	245	264	259
<b>GD 318.</b>	355	500	323	370	264	384
<b>GD 418.</b>	355	625	323	495	264	509

